

HALE *Premier*

ZG RECLINER

ASSEMBLY GUIDE



©2024 Relax The Back. Patents and intellectual property rights enforced.
HALE ZG-NA-A1



HALE Premier ZG RECLINER

ASSEMBLY GUIDE

UNPACK THE BOXES

Confirm that you have all of the following parts:



Chair



Body pad



Pillow



Power adapter

ASSEMBLY

1. Unfold the backrest frame (Fig.1).



(Fig.1)

2. Insert the “L” latches into both sides of the frame to secure (Fig.2).

“L” latch



(Fig.2)

3. Unfold the rear fabric cover over the “L” latches and press firmly to connect the hook-and-loop fasteners (Fig.3)

Hook-and-loop fasteners




(Fig.3)

4. Connect the power adaptor to the chair, then plug into a wall outlet (Fig.4).



(Fig.4)

5. Turn the dial clockwise or use the remote to raise the legrest (Fig.5).



(Fig.5)

6. Attach the legrest portion of the body pad onto the frame (Fig.6).




(Fig.6)

7. Unzip the seat fabric cover (Fig.7).




(Fig.7)

8. Pull the air hoses and heater wire harness through the hole in the seat fabric cover (Fig.8).




(Fig.8)

9. Connect the air hose harness and heater wire making sure they are under the seat spring, then zip the seat cover to close (Fig.9).



(Fig.9)



13. Zip the body pad over the backrest frame (Fig.13).



14. Thread the pillow flap through the retaining strap on the back of the body pad (Fig.14).



15. Hang the remote control onto the hook (Fig.15).

